



Samsung Galaxy J7 Home Button Flex (video) Replacement

Written By: Dozuki System

Galaxy J7 Home Button Flex with Earphone Jack

Repair Guide



INTRODUCTION

[video: <https://www.youtube.com/watch?v=cCBvgvxPu6g>]

How to fix insensitive Home Button? Is your Navigation Button intact but you just can't use it? Follow this video and repair it by yourself.



TOOLS:

- [Plastic Cards](#) (1)
- [Phillips #000 Screwdriver](#) (1)
- [Heat Gun](#) (1)
- [iFixit Opening Tools](#) (1)
- [iFixit Opening Picks set of 6](#) (1)



PARTS:

- [Original Home Button Flex with Earphone Jack for Samsung Galaxy J7](#) (1)

To reassemble your device, follow these instructions in reverse order.